
YAMAHA



PARTS CATALOGUE

WaveRunner VX700

VX700-J (F1V5/6AEE/6AE1)

1JF1V-100E1

( )

YAMAHA
GENUINE
Parts & Accessories

VX700-J
PARTS CATALOGUE

1st edition, July 2009

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
   It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations
   The following abbreviations are used in this Parts Catalogue.

   "UR" Use specified parts number.
   "UN" Use as many as needed.
   "AP" Alternate Parts
   "LM" Locally Made (Parts need to be ordered locally)
   "F#" Frame No. (Applicable machine No.)
   "O/S" Over Size

3. The number of components for assembly
   - Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
   - The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5–83310–60	FRONT FLASHER LIGHT ASSY	2	
115–83311–60	.BULB (6V–18W)	1	

4. Applicable colours of graphics are represented in the "REMARKS" as shown below.


PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4–24110–00–X5	FUEL TANK COMP.	2	MXR
3J1–24240–10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.


6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Engine Serial No.



Hull Serial No.



8. Applicable Colour Code (The (*) mark shows Model colour.)

Abbreviation	Colour Name	Colour Code
NMC(*)	GRAY METALLIC C	008S
PURW(*)	PURE WHITE	0240
SS4(*)	BLACK SOLID 4	008P
LNMP	LIGHT GRAY METALLIC P	0925
YB	YAMAHA BLACK	0033

9. Quantity Column Information

Column No.	Name Of Q'ty Column	Destination
1	OTH	OTHERS

10. Applicable Starting Serial No.

Engine Serial No.


Serial No.	Name Of Q'ty Column	Model Code
6AE-1007201	OTH	6AEE

Hull Serial No.

Serial No.	Name Of Q'ty Column	Model Code
F1V-807301	OTH	F1V5

CONTENTS


INDEX



F1V5100-J010

FIG. 1 CYLINDER & CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	62T–11311–00–8S	CYLINDER 1	1					
2	6E5–11325–00	ANODE	1					
3	98780–04015	SCREW, FLAT HEAD	1					
4	93606–12019	PIN, DOWEL	4					
5	6M6–11351–A2	GASKET, CYLINDER	1					
6	90119–10M56	BOLT, WITH WASHER	4					
7	90119–10M07	BOLT, WITH WASHER	2					
8	62T–11111–00–8S	HEAD, CYLINDER 1	1					
9	6K8–51129–00	.NIPPLE	1					
10	90340–08M04	PLUG, STRAIGHT SCREW	1					
11	90430–08020	GASKET	1					
12	62T–11181–01	GASKET, CYLINDER HEAD 1	1					
13	90119–08M96	BOLT, WITH WASHER	10					
14	62T–W0090–03–8S	CRANK CYLINDER ASSY	1					
15	62T–15100–00–8S	CRANKCASE ASSY	1					
16	62T–14251–10	.NIPPLE	1					
17	90380–12M29	.BUSH, SOLID	1					
18	90119–08M55	BOLT, WITH WASHER	4					
19	61L–44532–00	STOPPER, UPPER MOUNT	1					
20	90109–08M56	BOLT	4					
21	6R7–21415–01–94	BRACKET, FRONT UPPER 1	1					
22	6R7–21425–01–94	BRACKET, REAR UPPER 1	1					
23	90119–10M02	BOLT, WITH WASHER	4					
24	90119–10M00	BOLT, WITH WASHER	1					
25	90119–10M03	BOLT, WITH WASHER	1					
26	90119–10M01	BOLT, WITH WASHER	1					
27	62E–44517–A1–8P	MOUNT RUBBER	4					



F1V5100-J010

FIG. 1 CYLINDER & CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
28	90119–08856	BOLT, WITH WASHER	4					
29	F1V–U721B–03	SPACER,ENGINE MOUNT	2					
30	F1V–U146H–01	SPACER, BRKT.	2					
31	90119–08823	BOLT, WITH WASHER	12					
32	90201–099U3	WASHER, PLATE	4					
33	EU0–U7354–00–01	SHIM (T=0.1)	4					UR
	EU0–U7354–00–03	SHIM (T=0.3)	4					UR
	EU0–U7354–00–05	SHIM (T=0.5)	4					UR
	EU0–U7354–00–10	SHIM (T=1.0)	4					UR
	EU0–U7354–00–20	SHIM (T=2.0)	4					UR





FIG. 2 CRANKSHAFT & PISTON


REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	62T–11400–02	CRANKSHAFT ASSY	1					
2	6M6–11412–00	.CRANK 1	1					
3	6M6–11422–00	.CRANK 2	2					
4	6M6–11431–10	.CRANK 3	1					
5	6M6–11442–01	.CRANK 4	1					
6	93305–30601	.BEARING	1					
7	64X–11651–01	.ROD, CONNECTING	2					
8	82M–11685–00	.WASHER, CRANK PIN	4					
9	93306–207U2	.BEARING	2					
10	65U–11515–00	.SEAL, LABYRINTH 1	1					
11	93310–525U3	.BEARING	2					
12	93306–307U3	.BEARING	1					
13	62T–45526–00	.COLLAR, DRIVE SHAFT	1					
14	93440–80023	.CIRCLIP	1					
15	93102–36M33	OIL SEAL	1					
16	93101–36M46	OIL SEAL	1					
17	93103–32M01	OIL SEAL	1					
18	62T–11631–02–92	PISTON (STD)	2					
	62T–11635–02	PISTON (0.25MM O/S)	2					AP
	62T–11636–02	PISTON (0.50MM O/S)	2					AP
19	61X–11603–01	PISTON RING SET (STD)	2					
	61X–11604–01	PISTON RING SET (0.25MM O/S)	2					AP
	61X–11605–01	PISTON RING SET (0.50MM O/S)	2					AP
20	62T–11633–00	PIN, PISTON	2					
21	93310–320U2	BEARING	2					
22	90201–20M04	WASHER, PLATE	4					
23	93450–21053	CIRCLIP	4					



F1V1100-E020

FIG. 2 CRANKSHAFT & PISTON

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
24	6M6–45813–32–8P	FLANGE, COUPLING	1					
25	62T–45127–00	SEAL	1					
26	93603–10049	PIN, DOWEL	4					
27	93604–07141	PIN, DOWEL	1					



F1V1100-E030

FIG. 3 INTAKE

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	62T–24313–01	PIPE 3	1					
2	90465–11M10	CLAMP	2					
3	90116–08M60	BOLT, STUD	4					
4	90179–08M15	NUT	4					
5	62T–13556–00	GASKET, MANIFOLD	1					
6	62T–13555–00–94	MANIFOLD, INTAKE	1					
7	62T–13624–00	PLATE,REED VALVE	1					
8	62T–13566–00	GASKET	2					
9	97013–06035	BOLT	3					
10	92903–06600	WASHER, PLATE	3					
11	97013–06025	BOLT	8					
12	92903–06600	WASHER, PLATE	8					
13	62T–13610–00	REED VALVE ASSY	2					
14	62T–W0004–00	.REED SET	1					
15	97880–05016	SCREW, PAN HEAD	4					
16	92990–05600	WASHER, PLATE	4					
17	62T–14527–02	PLATE	1					
18	97013–06016	BOLT	2					
19	92903–06600	WASHER, PLATE	2					
20	62T–24314–01	PIPE 4	1					
21	90465–11M10	CLAMP	2					
22	62T–14284–01–8S	COVER, CARBURETOR 2	1					
23	6E5–11372–01	.NIPPLE, HOSE	1					
24	6H1–14485–00	.PIPE, JOINT	1					
25	97013–06020	BOLT	6					
26	92903–06600	WASHER, PLATE	6					
27	62T–13674–00	GASKET, AIR COOLER COVER 1	2					





FIG. 3 INTAKE


REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
28	62T–14255–00	PLATE	1					
29	97013–06012	BOLT	1					
30	92903–06600	WASHER, PLATE	1					
31	90109–06M66	BOLT	1					
32	90201–06M31	WASHER, PLATE	1					
33	62T–14451–00	ELEMENT, AIR CLEANER	2					
34	62T–14283–01	COVER, CARBURETOR 1	1					
35	62T–14419–00	PIPE	1					
36	90119–05M02	BOLT, WITH WASHER	6					
37	62T–14435–00	GROMMET	1					
38	93210–13M63	O-RING	1					

FIG. 4 CARBURETOR



F0M5100-0040

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	62T–14301–03	CARBURETOR ASSY 1	1					
2	62T–14302–03	CARBURETOR ASSY 2	1					
3	47X–14133–00	.SPRING, THROTTLE STOP	1					CARBURETOR 2
4	812–14235–00	.WASHER, NEEDLE	4					
5	6M6–14521–00	.SCREW, ADJUST	1					CARBURETOR 2
6	812–14147–00	.O-RING	2					
7	6K8–14946–10	.METERING NEEDLE	2					
8	6K8–14471–10	.CAP, CARBURETOR	2					
9	3KW–14932–00	.SPRING, THROTTLE 2	3					
10	6M6–14503–00	.SCREW	2					
11	3G2–14231–26	.JET, MAIN (#130)	1					CARBURETOR 1
12	3G2–14231–24	.JET, MAIN (#120)	1					CARBURETOR 2
13	6K8–14564–00	.O-RING	2					
14	6K8–24411–20	.DIAPHRAGM	1					CARBURETOR 1
15	6M6–24413–01	.BODY 2	1					CARBURETOR 1
16	65U–24421–00	..VALVE, CHECK	2					CARBURETOR 1
17	65U–24492–00	..BUSH, FUEL PUMP	2					CARBURETOR 1
18	6K8–24421–10	.VALVE, CHECK	1					CARBURETOR 1
19	6K8–24431–20	.GASKET, FUEL PUMP 1	1					CARBURETOR 1
20	6K8–24452–10	.COVER	1					UR CARBURETOR 1
	62T–14293–00	.COVER 1	1					UR CARBURETOR 2
21	97980–05330	.SCREW, WITH WASHER	4					CARBURETOR 1
22	6K8–14563–00	.O-RING	1					CARBURETOR 1
23	6K8–14503–02	.SCREW	2					
24	6K8–14521–10	.SCREW	4					
25	830–1423A–64	.JET, MAIN (# 67.5)	2					
26	98580–05018	.SCREW, PAN HEAD	4					CARBURETOR 2



F0M5100-0040

FIG. 4 CARBURETOR

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
27	6K8–14527–11	.PLATE	2					
28	439–14186–00	.PIN, FLOAT	2					
29	6R7–24412–01	.BODY 1	2					
30	6K8–14523–11	.SCREW, STOP	4					
31	6R7–14569–00	.STRAINER	2					
32	61X–14916–16	.NEEDLE	2					
33	6K8–14547–01	.ARM, FLOAT	2					
34	6R7–14253–00	.SPRING	2					
35	6R7–14541–00	.DIAPHRAGM, PUMP	2					
36	6R7–14542–00	.BODY, PUMP 1	2					
37	6K8–14536–11	.GASKET	2					
38	97880–05012	.SCREW, PAN HEAD	8					
39	65U–14923–10	.SCREW, PILOT	2					
40	6K8–14589–00	.SPRING	2					
41	822–14235–00	.WASHER, NEEDLE	4					
42	583–14561–00	.O-RING	2					
43	6K8–14521–00	.SCREW, ADJUST	1					CARBURETOR 1





FIG. 5 OIL PUMP

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	61X–13200–12	OIL INJECTION PUMP ASSY	1					
2	90445–11037	HOSE (L680)	1					
3	90465–11M10	CLAMP	1					
4	90447–13002	TUBE (L530)	1					
5	6R8–13116–A0	GASKET, PUMP CASE	1					
6	97095–06035	BOLT	2					
7	92995–06600	WASHER	2					
8	90445–07009	HOSE (L85)	1					
9	67X–13183–00	VALVE, CHECK	1					
10	90446–07M18	HOSE (L210)	1					
11	90465–11M10	CLAMP	1					
12	90468–02001	CLIP	3					
13	90445–07008	HOSE (L70)	1					
14	67X–13183–00	VALVE, CHECK	1					
15	90446–07M48	HOSE (L450)	1					
16	90465–11M10	CLAMP	1					
17	90468–02001	CLIP	3					
18	90465–08M69	CLAMP	1					
19	90464–10M38	CLAMP	2					
20	90465–11829	CLAMP	1					




F1V2100-F060

FIG. 6 EXHAUST 1


REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	62T–14711–10–94	MUFFLER 1	1					
2	6K8–51129–00	.NIPPLE	1					
3	62T–14613–01	GASKET, EXHAUST PIPE	1					
4	90105–10M60	BOLT, FLANGE	8					
5	62T–14712–00–94	RING, JOINT	1					
6	6K8–51129–00	.NIPPLE	1					
7	62T–14749–02	GASKET, MUFFLER DAMPER 2	1					
8	93605–12M21	PIN, DOWEL	2					
9	97013–08075	BOLT	2					
10	92903–08600	WASHER, PLATE	2					
11	90119–08M11	BOLT, WITH WASHER	2					
12	90445–14M24	HOSE (L260)	1					
13	90465–11M10	CLAMP	2					
14	63N–24378–00	PIPE, JOINT 3	1					
15	90445–21010	HOSE (L70)	1					
16	90445–14M33	HOSE (L1150)	1					
17	90447–15003	TUBE	1					
18	90445–14M25	HOSE (L380)	1					
19	90465–11M10	CLAMP	1					
20	90446–20M31	HOSE (L340)	1					
21	90465–11M10	CLAMP	1					
22	90465–11M59	CLAMP	2					
23	62T–14721–00–8S	MUFFLER 2	1					
24	62T–14485–10	PIPE, JOINT	1					
25	90105–10M60	BOLT, FLANGE	2					
26	62T–41113–00–8S	OUTER COVER, EXHAUST	1					
27	62T–41114–01	GASKET, EXHAUST OUTER COVER	1					

FIG. 6 EXHAUST 1



F1V2100-F060

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
28	97013–06025	BOLT	6					
29	92903–06600	WASHER, PLATE	6					
30	62T–14625–00	JOINT, EXHAUST 2	1					
31	90450–99M06	HOSE CLAMP ASSY	2					
32	62T–14615–01	JOINT, EXHAUST 1	1					
33	6R3–24377–00	PIPE, JOINT 2	1					
34	90465–11M10	CLAMP	2					
35	90450–99M01	HOSE CLAMP ASSY	1					
36	90450–99M02	HOSE CLAMP ASSY	1					
37	62T–41121–00–8S	INNER COVER,EXHAUST	1					
38	62T–41122–00	GASKET, EXHAUST INNER COVER	1					
39	62T–41123–01–8S	OUTER COVER, EXHAUST	1					
40	62T–41124–00	GASKET, EXHAUST OUTER COVER	1					
41	63N–15761–00	SEAL, RUBBER 1	1					
42	97013–06070	BOLT	6					
43	92903–06600	WASHER, PLATE	6					
44	62T–14771–00–94	STAY, MUFFLER 1	1					
45	90119–10M17	BOLT, WITH WASHER	4					
46	90105–10M88	BOLT, FLANGE	2					
47	6AE–14752–00	PIPE, OUTLET	1					
48	90450–70M03	HOSE CLAMP ASSY	1					
49	90445–21009	HOSE (L1030)	1					
50	90445–14M14	HOSE (L330)	1					
51	90446–20M13	HOSE (L260)	1					
52	64X–12581–00	JOINT, HOSE 1	1					
53	90450–14M05	HOSE CLAMP ASSY	2					
54	90450–18M09	HOSE CLAMP ASSY	1					



F1V2100-F060

FIG. 6 EXHAUST 1

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
55	6AE–12564–00	PIPE, WATER	1					
56	64T–12580–00	JOINT ASSY	1					
57	682–84385–01	CAP,1	1					
58	EU0–61652–00	NUT	1					
59	67X–E2590–10	CONDUCTION ASSY	1					
60	90601–118UF	BAND, HOSE 18	1					




FIG. 7 FUEL

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	90445–10037	HOSE (L1220)	1					
2	90447–13003	TUBE	1					
3	90465–12M56	CLAMP	1					
4	90445–10036	HOSE (L1220)	1					
5	90447–13003	TUBE	1					
6	90465–11M10	CLAMP	2					
7	66V–24560–00	FILTER ASSY	1					
8	66V–24500–02	FUEL COCK ASSY 1	1					
9	6K8–24524–10	LEVER, COCK	1					
10	90445–11040	HOSE (L700)	1					
11	90465–11M10	CLAMP	1					
12	90445–11006	HOSE (L580)	1					
13	90465–11M10	CLAMP	1					
14	90445–11008	HOSE (L550)	1					
15	90465–11M10	CLAMP	1					
16	90465–11829	CLAMP	2					
17	6G8–24376–00	PIPE, JOINT 1	1					
18	90465–11829	CLAMP	1					
19	90170–22187	NUT	1					
20	90202–229U1	WASHER, PLATE	1					
21	90159–04800	SCREW, WITH WASHER	1					
22	EU0–U7817–00	HOLDER, FILTER	1					
23	90465–11829	CLAMP	2					





FIG. 8 JET UNIT 1


REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	6D3–R1333–01	SCREEN, INTAKE	1					
2	6AE–G5831–00	PLATE, TRANSOM	1					
3	99590–14016	PIN, DOWEL	2					
4	90119–10810	BOLT, WITH WASHER	4					
5	66V–51312–01–94	HOUSING, IMPELLER	1					
6	90119–06893	BOLT, WITH WASHER	1					
7	93606–12019	PIN, DOWEL	2					
8	66V–51315–00–94	DUCT, IMPELLER	1					
9	66V–46882–00	FILTER	1					
10	66V–42414–00	O-RING	2					
11	66V–45214–00–94	COVER, WATER INLET 1	1					
12	90119–06897	BOLT, WITH WASHER	4					
13	93306–27211	BEARING	1					
14	65V–45538–00	SPACER 1	1					
15	93306–205U0	BEARING	1					
16	6D3–45514–00	SHAFT, DRIVE 4	1					
17	93101–21001	OIL SEAL	1					
18	93101–21002	OIL SEAL	1					
19	6D3–45511–00	SHAFT, DRIVE	1					
20	65A–R1326–10	CAP	1					
21	93210–464A3	O-RING	1					
22	90119–069UB	BOLT, WITH WASHER	3					
23	6D3–R1319–00	CAP, IMPELLER	1					
24	6AE–R1321–00	IMPELLER	1					
25	6D3–R1318–00	NOZZLE	1					
26	90445–16006	HOSE (L260)	1					
27	90601–118UF	BAND, HOSE 18	1					

FIG. 8 JET UNIT 1



F1V5100-J080


REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
28	90445–14008	HOSE (L355)	1					
29	90446–20MF5	HOSE (L320)	1					
30	90465–11829	CLAMP	2					
31	90119–10806	BOLT, WITH WASHER	4					
32	6D3–R1341–00	BRACKET 1	1					
33	6D3–R1313–00	NOZZLE, DEFLECTOR	1					
34	90119–08840	BOLT, WITH WASHER	2					
35	90387–08M06	COLLAR	2					
36	F1S–U725E–01	WASHER	2					
37	90201–10801	WASHER, PLATE	2					
38	9572R–10300	NUT, NYLON	4					
39	F1K–U273B–05	PLATE 2	1					
40	90119–08823	BOLT, WITH WASHER	4					
41	F1G–U8572–02	BRACKET 2	2					
42	F1K–U8577–01	BRACKET, 3	1					
43	90119–06896	BOLT, WITH WASHER	2					
44	90119–10809	BOLT, WITH WASHER	2					
45	F1K–U7557–01	BRACKET	1					
46	90109–08041	BOLT	2					
47	92990–12200	WASHER, PLAIN	2					
48	90430–12002	GASKET	2					
49	F1K–U757E–01	PLATE, RUBBER 1	1					
50	F1K–U757F–01	PLATE, RUBBER 2	1					
51	90387–06080	COLLAR	6					
52	90119–06827	BOLT, WITH WASHER	4					
53	90101–069U0	BOLT	2					
54	9572R–06300	NUT, NYLON	2					



F1V5100-J080

FIG. 8 JET UNIT 1


REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
55	90119–089U7	BOLT, WITH WASHER	2					



F1V3100-G090

FIG. 9 JET UNIT 2

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	61X–4581J–00	RUBBER SHAFT COUPLING	1					
2	6D3–45332–00–94	HOUSING, BEARING	1					
3	6D3–45235–00	DAMPER	1					
4	93101–25M55	OIL SEAL	2					
5	93430–47M04	CIRCLIP	1					
6	93306–205A3	BEARING	1					
7	93101–25M56	OIL SEAL	1					
8	90480–06M46	GROMMET	1					
9	6AE–51323–00	SHAFT, COUPLER	1					
10	6M6–45813–22–8P	FLANGE, COUPLING	1					
11	90201–24800	WASHER, PLATE	1					
12	90119–06891	BOLT, WITH WASHER	2					
13	90387–06M60	COLLAR	2					
14	63N–51381–00	COVER	1					
15	F1K–U883E–01	JOINT, PIPE	1					
16	90109–06832	BOLT	3					
17	F1V–U2155–01	CAP	1					
18	90119–089UU	BOLT, WITH WASHER	4					
19	90601–162U5	BAND, HOSE 62	2					
20	F1K–U883B–00	PIPE, 1	1					



GH14010-4100

FIG. 10 GENERATOR

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	62T–85550–00	ROTOR ASSY	1					
2	62T–85560–00	BASE ASSY	1					
3	62T–85520–01	.COIL, CHARGE	1					
4	62T–85533–00	.COIL, LIGHTING	1					
5	6M6–85580–00	.COIL, PULSER	1					
6	62T–85515–00	.LEAD WIRE ASSY	1					
7	97902–05125	.SCREW, WITH WASHER	4					
8	97902–04122	.SCREW, WITH WASHER	2					
9	97802–04008	.SCREW, PAN HEAD	1					
10	97880–06016	SCREW, PAN HEAD	2					
11	92990–06600	WASHER, PLATE	2					
12	90280–05013	KEY, WOODRUFF	1					
13	90109–10M47	BOLT	1					
14	6R8–81337–00–8S	COVER, FLYWHEEL	1					
15	90380–12M29	.BUSH, SOLID	1					
16	6M6–81365–A0	GASKET, HOLE COVER	1					
17	93606–12019	PIN, DOWEL	2					
18	97095–06025	BOLT	7					
19	92995–06600	WASHER	7					




FIG. 11 STARTING MOTOR

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	6M6–81800–10	STARTING MOTOR ASSY	1					
2	3AJ–81809–00	.WASHER KIT	1					
3	6M6–81840–10	.BRUSH HOLDER ASSY	1					
4	11H–81844–00	.GASKET	2					
5	6M6–81826–00	.BOLT	2					
6	6M6–81850–00	.ARMATURE ASSY	1					
7	6M6–81820–00	.REAR BRACKET ASSY	1					
8	6M6–81830–00	.FRONT BRACKET ASSY	1					
9	26H–81847–00	..O-RING	1					
10	97513–08540	BOLT, WITH WASHER	1					
11	97013–08035	BOLT	1					
12	92903–08600	WASHER, PLATE	1					
13	92990–06100	WASHER, SPRING	1					
14	95380–06700	NUT	1					
15	6M6–8183E–01	IDLE GEAR COMP.	1					
16	6M6–81866–00	.WEIGHT SPRING	1					
17	6M6–81865–00	.WEIGHT HOLDER	1					
18	93440–25M08	.CIRCLIP	1					
19	93450–18M06	.CIRCLIP	1					
20	90501–14M73	SPRING, COMPRESSION	1					
21	92903–06600	WASHER, PLATE	2					





FIG. 12 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1V–U815D–00	BRACKET, ELECTRIC BOX	1					
2	9572R–08300	NUT, FLANGE	4					
3	9299R–08200	WASHER	2					
4	62L–8552A–00–8P	HOUSING	1					
5	6M6–8552E–01	COVER, CASE	1					
6	6M6–81921–00	GASKET, TERMINAL	1					
7	97780–60525	SCREW, TAPPING	14					
8	6M6–81844–00	GASKET	1					
9	6M6–8132W–00	CAP	1					
10	6K8–82150–01	FUSE HOLDER ASSY	1					
11	6G1–82151–00	.FUSE (10A)	1					
12	6K8–82159–00	.FUSE SPEAR (10A)	1					
13	62T–85540–01	C.D.I. UNIT ASSY	1					
14	90464–06M29	CLAMP	1					
15	97880–06016	SCREW, PAN HEAD	2					
16	92990–06600	WASHER, PLATE	2					
17	68N–81940–00	STARTER RELAY ASSY	1					
18	97095–06010	BOLT	2					
19	92995–06100	WASHER, SPRING	2					
20	92995–06600	WASHER	2					
21	6M6–81960–A0	RECTIFIER & REGULATOR ASSY	1					
22	90465–06M86	CLAMP	1					
23	97880–06016	SCREW, PAN HEAD	2					
24	92990–06600	WASHER, PLATE	2					
25	62E–85570–11	IGNITION COIL ASSY	1					
26	62E–82371–11	.CAP, PLUG	1					
27	62E–82351–01	.TUBE, CORD	1					

FIG. 12 ELECTRICAL 1



REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
28	62E–82371–11	.CAP, PLUG	1					
29	62E–82352–01	.TUBE, CORD 2	1					
30	90480–06M43	.GROMMET	2					
31	90465–11M10	.CLAMP	4					
32	97880–06030	SCREW, PAN HEAD	2					
33	92990–06600	WASHER, PLATE	2					
34	97880–06016	SCREW, PAN HEAD	2					
35	92990–06600	WASHER, PLATE	2					
36	62T–82361–00	CLAMP, CORD	1					
37	94702–00195	PLUG, SPARK (NGK BR8HS)	2					
38	6AE–82553–00	EXTENSION, WIRE LEAD	1					
39	62T–82560–11	THERMO SWITCH ASSY	1					
40	97095–06016	BOLT	2					
41	92995–06100	WASHER, SPRING	2					
42	6AE–82117–20	WIRE, LEAD	1					
43	6B6–83623–00	MARK 3	1					




FIG. 13 ELECTRICAL 2

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1W–U828M–00	BASE, CLAMP	1					
2	90464–32801	CLAMP	1					
3	90267–489U6	RIVET, BLIND	1					
4	EU0–82110–09	BATTERY ASSY (YB16CL-B)	1					YUASA
5	F1K–U8221–00	PAD, BATTERY	1					
6	F1K–U8211–01	CASE, BATTERY	1					
7	F1K–U5772–03	HOOK A	4					
8	90267–489U1	RIVET,BLIND	4					
9	F1K–U821D–01	BAND, BATTERY 1	2					
10	F0D–U785G–10	HOSE, AIR VENT	1					
11	90467–089U1	CLIP	1					
12	GJ3–6215F–00	NIPPLE	1					
13	90465–11829	CLAMP	1					
14	F1V–6820A–01	METER ASSY	1					
15	90111–05008	BOLT,HEX. SOCKET BUTTON	4					
16	GU2–6822E–01	GROMMET	1					
17	90601–200U1	BAND	1					
18	F0V–U824B–04	SENDER, FUEL	1					
19	F0V–H369N–00	.FLOAT	1					
20	GJ8–U824C–02	SENDER, OIL	1					
21	F1V–U273C–01	COVER,PLATE	1					
22	90150–05807	SCREW, ROUND HEAD	4					
23	F1W–U828M–00	BASE, CLAMP	5					
24	90267–48802	RIVET, BLIND	5					
25	90464–32801	CLAMP	4					
26	90601–200U2	BAND	1					
27	F1W–U828M–00	BASE, CLAMP	2					





FIG. 13 ELECTRICAL 2

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
28	90464–32801	CLAMP	1					
29	90601–200U2	BAND	1					
30	90267–489U6	RIVET, BLIND	2					
31	6AE–82117–00	WIRE, LEAD	1					
32	63N–82117–10	WIRE, LEAD	1					




F1V1100-E140

FIG. 14 ENGINE HATCH 1

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1K–U516N–60–P0	COVER, ENGINE HATCH	1					LNMP
2	F1K–U2723–00	SEAL	1					
3	90269–09805	RIVET	1					
4	F1K–U266C–00	PACKING 4	2					
5	9299R–06200	WASHER	4					
6	9572R–06300	NUT, NYLON	4					
7	90183–06902	NUT, SPRING	2					
8	90119–06882	BOLT, WITH WASHER	8					
9	F1K–U517H–01	LID HATCH	1					
10	F0X–6517R–01	PIN, HINGE	2					
11	GU2–62875–01	LOCK	1					
12	90605–502U1	PLUG, BLIND	1					
13	F1K–U519D–00	PACKING CASE	1					
14	F1V–U7437–01	COVER (LH)	1					
15	90267–48824	RIVET, BLIND	2					
16	F1V–U7437–10	COVER (RH)	1					
17	90267–48824	RIVET, BLIND	2					

FIG. 15 ENGINE HATCH 2



F1K1100-D200

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1K–U517B–60–P0	LID, ENGINE ROOM	1					LNMP
2	F1K–U2103–00	VENTILATOR COVER COMP., 2	1					
3	90267–48809	RIVET, BLIND	7					
4	F1K–U2663–00	PACKING 1	1					
5	F1K–U266B–00	PACKING 3	2					
6	F1K–6517C–00	LOCK, LID	1					
7	90159–059U2	SCREW, WITH WASHER	2					
8	F1K–U515A–00	HINGE ASSY.	1					
9	F1K–U518E–04	.PLATE, HINGE LID	1					
10	F1K–U517D–05	.HINGE, LID	1					
11	F1K–U135C–00	.ROLLER, DETENT	1					
12	F1K–U517R–00	.PIN, HINGE	2					
13	F1K–U471E–03	.SPACER 1	1					
14	F1K–U283B–02	.SPRING, TORSION	1					
15	90105–06826	BOLT, FLANGE	2					
16	9572R–06300	NUT, NYLON	2					
17	9299R–06200	WASHER	2					
18	90119–069UH	BOLT, WITH WASHER	4					
19	F1K–U517F–01	HOOK,LID LOCK	1					
20	90119–069UH	BOLT, WITH WASHER	2					
21	F1K–U475F–01	PLATE, LOKER BOW	1					
22	90269–08801	RIVET	4					
23	F1K–U759C–00	MAT 2	2					
24	F1K–U5983–01	BOX, FIRE EXTINGUISHER	1					
25	F1K–U828K–00	BAND, 1	1					




FIG. 16 HULL & DECK

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	90445–20805	HOSE (L710)	2					
2	61X–51162–00	JOINT, HOSE	1					
3	90467–18804	CLIP	2					
4	FN8–6269B–00	SPOUT	1					
5	EU0–61652–00	NUT	1					
6	90601–118UF	BAND, HOSE 18	1					
7	F1B–U761D–02	STRAINER, BILGE	1					
8	F1W–U828M–00	BASE, CLAMP	1					
9	90464–32801	CLAMP	1					
10	90267–489U8	RIVET, BLIND	1					
11	90601–200U1	BAND	1					
12	90467–21800	CLIP	1					
13	90467–200A0	CLIP	1					
14	90467–210A0	CLIP	1					
15	F1K–61628–00	STERN EYE	2					
16	9572R–08300	NUT, FLANGE	4					
17	GP7–U4953–10	PLATE A	4					
18	F1B–U1653–01	PACKING	2					
19	F0X–61624–00	BOWEYE 1	1					
20	99780–12600	NUT.HEX.(COARS)	2					
21	92990–12200	WASHER, PLAIN	2					
22	F0X–61637–00	WASHER	2					
23	F0X–61652–00	NUT (BOLT/NUT)	2					
24	90110–06040	BOLT, HEXAGON SOCKET HEAD	2					
25	F1S–U883N–01	STABILIZER LH	1					BLACK
26	F1S–U883P–01	STABILIZER RH	1					BLACK
27	F1X–U883T–01	BRACKET,STABILIZER	2					





FIG. 16 HULL & DECK

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
28	90105–08860	BOLT, FLANGE	10					
29	F2N–U8169–00	SPACER	10					
30	F1S–U2280–00	DRAIN PLUG ASSY.	2					
31	F1S–U2285–00	PACKING, DRAIN	2					
32	9788R–05025	SCREW, PAN HEAD	4					
33	9299R–05200	WASHER	4					
34	9572R–05300	NUT, FLANGE	4					
35	90464–40825	CLAMP	2					
36	F1K–U759C–00	MAT 2	1					



F1K1100-D220

FIG. 17 GUNWALE & MAT

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1K–U2501–02	BOW GUNWALE COMP.	1					GRAY
2	F1K–U2521–02	PLATE	1					
3	F1W–U491K–00	BOLT, SPECIAL	3					
4	90111–06803	BOLT,HEX. SOCKET BUTTON	2					
5	9299R–06200	WASHER	5					
6	9572R–06300	NUT, NYLON	5					
7	F1K–U2512–03	GUNWALE, SIDE	2					GRAY
8	F1K–U2519–20	INNER,GUNWALE	2					YAMAHA BLACK
9	90169–059U1	SCREW,TAPPING	30					
10	F1K–U251D–01	GUNWALE, STERN 1	1					GRAY
11	F1K–U251E–01	GUNWALE, STERN 2	1					GRAY
12	90267–47801	RIVET, BLIND	9					
13	F1K–U3581–10	MAT, UPPER	1					GRAY
14	F1K–U351H–10	MAT, STEP 1	4					GRAY
15	F1K–U351J–10	MAT, STEP 2	2					GRAY
16	F1K–U351K–10	MAT, STEP 3	1					GRAY
17	F1K–U351M–10	MAT, STEP 4	1					GRAY





FIG. 18 VENTILATION

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1K–U2127–00	BASE, AIR INTAKE	2					
2	F1K–U213G–00	HOSE, VENTILATOR 2	2					
3	F1W–U828M–00	BASE, CLAMP	2					
4	90267–48802	RIVET, BLIND	2					
5	90601–200U2	BAND	1					
6	90601–200U2	BAND	2					
7	90464–99804	CLAMP	2					
8	90601–200U7	BAND	1					
9	F1W–U828M–00	BASE, CLAMP	2					
10	90464–32801	CLAMP	1					
11	90267–489U6	RIVET, BLIND	2					
12	F1K–U2187–00	BOX, INDUCTION 1	1					
13	F1K–U2188–00	BOX, INDUCTION 2	1					
14	90267–48806	RIVET, BLIND	8					



F1V4100-H190

FIG. 19 SEAT & UNDER LOCKER

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1K–U371A–12	DOUBLE SEAT ASSY	1					
2	F1K–U371B–10	.COVER, SEAT 1	1					
3	F1K–U2664–01	.PACKING	1					
4	F1B–U3850–02	.SEAT LOCK ASSY	1					
5	90119–069UP	.BOLT, WITH WASHER	2					
6	F1K–U378C–00	STAY, SEAT 1	1					
7	90201–099U3	WASHER, PLATE	1					
8	9572R–08300	NUT, FLANGE	2					
9	F1K–U271B–04	GRIP, HAND	1					
10	90119–06820	BOLT, WITH WASHER	4					
11	9299R–06200	WASHER	4					
12	9572R–06300	NUT, NYLON	4					
13	F1K–61628–00	STERN EYE	1					
14	GP7–U4953–10	PLATE A	2					
15	F1V–U826C–01	BRACKET	1					
16	9572R–08300	NUT, FLANGE	2					
17	F1K–U3774–00	PIN	1					
18	90119–10804	BOLT, WITH WASHER	1					
19	9299R–10200	WASHER	1					




FIG. 20 OIL TANK

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1V–U775B–00	TANK, OIL	1					
2	6J8–13411–00	STRAINER, OIL	1					
3	6J8–13414–00	GASKET, STRAINER COVER	1					
4	GJ3–U778C–00	PACKING,OIL CAP	1					
5	F0X–U778E–01	PACKING,OIL FILLER	1					
6	F0X–U778B–00	CAP,OIL FILLER	1					
7	F0X–U778D–00	SOCKET,OIL FILLER	1					
8	EU0–U7835–00	CHAIN BALL	1					
9	97780–04110	SCREW, TAPPING	1					
10	90267–40935	RIVET, BLIND	1					
11	F0X–U778H–01	NUT, OIL FILLER	1					
12	F1V–U776C–00	HOSE,OIL FILLER	1					
13	90601–142U6	BAND, HOSE 42	2					
14	F1V–U781E–01	BRACKET,FILTER	1					
15	90267–489U1	RIVET,BLIND	1					
16	FJ0–67766–00	ROLL OVER VALVE	1					
17	F1W–U828M–00	BASE, CLAMP	1					
18	90464–32801	CLAMP	1					
19	90267–489U6	RIVET, BLIND	1					
20	GU2–U785H–00	HOSE, AIR VENT 3	1					
21	90465–11829	CLAMP	2					





FIG. 21 FUEL TANK

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F2F–6214A–00	FILTER, VENT ASSY	1					
2	EW2–62142–00	.PLATE, FILTER	1					
3	70R–24543–00	.PLUG, DRAIN	1					
4	70R–24489–00	.O-RING	1					
5	90267–489U2	RIVET, BLIND	2					
6	90465–11829	CLAMP	2					
7	GP7–62159–02	SOCKET, VENTILATION	1					
8	90465–11829	CLAMP	1					
9	90267–489U6	RIVET, BLIND	2					
10	F1G–62149–00	PIPE, VENTILATION	1					
11	F1W–U828M–00	BASE, CLAMP	3					
12	90267–48802	RIVET, BLIND	3					
13	90464–32801	CLAMP	3					
14	GU2–U7711–01	TANK, FUEL	1					
15	90601–162U5	BAND, HOSE 62	1					
16	GJ1–U759B–00	MAT 1	2					
17	GJ1–U759C–00	MAT 2	1					
18	GH1–U759D–00	MAT 3	1					
19	GP7–U7831–11	CAP, FUEL FILLER	1					BLACK
20	GP7–U7832–01	PACKING	1					
21	GP7–U7833–11	SOCKET	1					BLACK
22	GP7–U7835–00	CHAIN BALL	1					
23	90169–049U1	TAPPING SCREW	1					
24	GP7–U7834–00	PACKING FUEL FILLER	1					
25	90267–329UR	RIVET, BLIND	1					
26	GP7–U783F–00	NUT, FUEL FILLER	1					
27	F1V–U7844–00	HOSE	1					



F1V1100-E210

FIG. 21 FUEL TANK

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
28	90601–155U4	BAND, HOSE 55	2					
29	EU0–67767–31	CHECK VALVE	1					
30	GP7–U785H–00	HOSE, AIR VENT 3	1					
31	90465–11829	CLAMP	3					
32	GJ3–U7856–10	HOSE, AIR VENT 3	1					
33	F0D–U7856–10	HOSE, AIR VENT 3	1					
34	F1K–U5772–03	HOOK A	4					
35	90267–489U1	RIVET,BLIND	4					
36	F1K–67743–00	BELT, TANK 1	1					
37	F1V–67743–00	BELT, TANK 1	1					
38	F1K–U759B–00	MAT 1	2					
39	F1W–U759C–01	MAT 2	4					
40	F1S–U8221–00	PAD, BATTERY	1					
41	F1K–U759C–00	MAT 2	2					





FIG. 22 EXHAUST 2

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	GJ3–U7550–00	WATER LOCK COMP.	1					
2	F1V–U892F–00	FLOATATION, BASE 1	1					
3	EU0–U821D–00	BAND,BATTERY 1	1					
4	GA7–65772–00	HOOK A	1					
5	90267–489U1	RIVET,BLIND	2					
6	F1K–U5772–03	HOOK A	1					
7	90267–489U1	RIVET,BLIND	1					
8	F1V–U7555–00	HOSE, EXHAUST	1					
9	90601–170UG	BAND, HOSE 70	3					
10	90601–200U7	BAND	1					
11	F1G–6753B–00	PILOT, WATER	1					
12	F1B–67564–00	GASKET	1					
13	F0X–62733–00	NUT	1					
14	F1W–U828M–00	BASE, CLAMP	1					
15	90267–48802	RIVET, BLIND	1					
16	90464–32801	CLAMP	1					
17	90601–118UF	BAND, HOSE 18	1					
18	90447–22800	TUBE	1					
19	90601–200U1	BAND	2					
20	F1W–U828M–00	BASE, CLAMP	1					
21	90267–48802	RIVET, BLIND	1					
22	90464–32801	CLAMP	1					
23	GJ3–U7560–01	EXHAUST, THRU-HALL COMP.	1					
24	GA9–U7525–00	PACKING	1					
25	90119–059U4	BOLT, WITH WASHER	3					



F1V4100-H230

FIG. 23 CONTROL CABLE

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1K–61481–01	CABLE, STEERING	1					
2	F1B–61438–00	.PACKING	1					
3	F1B–6151S–00	.NUT	1					
4	F1B–61461–02	.STUD, JOINT BALL	1					
5	GK5–U146F–00	SHAFT,JOINT BALL	1					
6	90201–06906	WASHER, PLATE	2					
7	9538R–06700	NUT	1					
8	90447–06803	TUBE	1					
9	F0M–U7252–00	CABLE, THROTTLE	1					
10	90447–09800	TUBE	1					
11	F1V–67242–01	CABLE, CHOKE	1					
12	EW2–67243–00	.KNOB	1					
13	90149–03930	.SCREW	1					
14	F0N–6724E–00	.NUT, COMPRESSION	1					
15	F0P–6724F–00	.NUT	1					




FIG. 24 STEERING 1

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1K–U1552–00	HANDLE	1					
2	GP7–U155D–01	GRIP, HANDLE	2					
3	GP7–U155F–00	GRIP, END	2					
4	90110–05908	BOLT, HEXAGON SOCKET HEAD	2					
5	F0D–67250–10	THROTTLE LEVER ASSY	1					
6	F0D–67255–02	.LEVER, THROTTLE	1					
7	EW2–67256–00	.SPRING	1					
8	EW2–67258–01	.WASHER	2					
9	EW2–67259–01	.E-RING	1					
10	F0D–67257–00	.SHAFT	1					
11	F1X–6725F–01	.BOLT, THROTTLE	2					
12	FK7–68310–07	SWITCH BOX ASSY	1					
13	EW2–68348–00	.LANYARD, STOP SWITCH	1					
14	97880–03008	.SCREW, PAN HEAD	2					
15	FK7–68312–02	.STOP BUTTON COMP	1					
16	FK7–68313–02	.START BUTTON COMP.	1					
17	97880–05025	.SCREW, PAN HEAD	2					
18	F1V–61400–00	STEERING MASTER ASSY	1					
19	F1K–6152M–00	.HOUSING ASSY	1					
20	F1K–6134M–00	.BUSH	1					
21	703–82591–00	.BAND	2					
22	F1K–6146H–10	.SPACER, BRKT.	1					
23	F1B–613C1–00	.SCREW	2					
24	F1K–6152D–00	.SHAFT	1					
25	F1K–6153R–00	.ARM ASSY.	1					
26	EU0–61461–02	..STUD, JOINT BALL	1					
27	95720–06300	..NUT, SELF-LOCKING	1					





FIG. 24 STEERING 1


REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
28	F1K–61355–00	.BOLT	1					
29	F1K–6142B–00	.PLATE, RETAINING	1					
30	95720–08300	.NUT, SELF-LOCKING	1					
31	F1S–68341–00	.BUZZER	1					
32	F1V–82144–00	.CASE ASSY.	1					
33	F1W–8A801–00	..CASE 1	1					
34	F1W–8A802–00	..CASE 2	1					
35	90111–05028	..BOLT,HEX. SOCKET BUTTON	4					
36	F1W–61516–00	.BOLT	4					
37	F1K–6143C–00	.SEAL, RUBBER	1					
38	F1K–U1467–01	BRACKET,STOPPER CABLE	1					
39	90267–48806	RIVET, BLIND	2					
40	90119–08836	BOLT, WITH WASHER	4					
41	F1K–U1468–03	STOPPER, CABLE	1					
42	90119–069UH	BOLT, WITH WASHER	1					
43	EU0–23814–30	HOLDER, HANDLE UPPER	2					
44	90119–089UU	BOLT, WITH WASHER	4					
45	F1K–U1949–00	PLUG	1					



F1K1100-D290

FIG. 25 STEERING 2

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1K–U156E–01	PAD 1	1					
2	F1K–U143D–01	PAD, STEERING 1	1					
3	F1K–U143E–01	PAD, STEERING 2	1					
4	F1K–U142D–00	COVER, PAD	1					
5	90154–06017	SCREW, BINDING	4					
6	90149–05903	SCREW	4					
7	90167–04003	SCREW, TAPPING	2					



F1V3100-G260

FIG. 26 GRAPHICS

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1V–U417F–20	GRAPHIC 5 (LH)	1					
2	F1V–U417G–20	GRAPHIC 6 (RH)	1					
3	F1V–U417H–20	GRAPHIC 7 (LH)	1					
4	F1V–U417J–20	GRAPHIC 8 (RH)	1					
5	F1V–U417K–20	GRAPHIC 9 (LH)	1					
6	F1V–U417L–20	GRAPHIC B (RH)	1					
7	F0V–U411C–10	EMBLEM, YAMAHA	2					
8	EU0–65986–10	TOOL SET	1					
9	EU0–65901–01	TOOL BAG	1					





FIG. 27 IMPORTANT LABELS


REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	F1B–U411C–02	EMBLEM, YAMAHA	1					
2	F1K–U411H–00	EMBLEM, TUNING FORK	1					
3	F1K–U41B1–11	LABEL, WARNING UNIFORM 1	1					
4	F1B–U41B1–21	LABEL, WARNING UNIFORM 1	1					
5	F0V–U41B1–31	LABEL, WARNING UNIFORM 1	1					
6	F1B–U41B2–01	LABEL, WARNING UNIFORM 2	1					
7	F1B–U415B–11	LABEL, WARNING(FUEL)	1					
8	F0V–U41DB–12	LABEL, WARNING BATTERY	1					
9	F1B–U41F5–21	LABEL, FIRE EXTINGUISHER 1	1					
10	GJ3–U416H–01	LABEL,WARNING(FRANCE)	1					
11	GA9–U418F–00	LABEL, RIGHTING	1					
12	F0V–U41E1–41	LABEL, SET 1	1					



F0V1100-E280

FIG. 28 REPAIR KIT 1

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	62T–W0001–02	GASKET KIT FOR ENGINE UNIT	1					
2	6M6–11351–A2	.GASKET, CYLINDER	1					
3	90430–08020	.GASKET	1					
4	62T–11181–01	.GASKET, CYLINDER HEAD 1	1					
5	93102–36M33	.OIL SEAL	1					
6	93101–36M46	.OIL SEAL	1					
7	93103–32M01	.OIL SEAL	1					
8	62T–14613–01	.GASKET, EXHAUST PIPE	1					
9	62T–14749–02	.GASKET, MUFFLER DAMPER 2	1					
10	62T–41114–01	.GASKET, EXHAUST OUTER COVER	1					
11	62T–41122–00	.GASKET, EXHAUST INNER COVER	1					
12	62T–41124–00	.GASKET, EXHAUST OUTER COVER	1					
13	62T–13556–00	.GASKET, MANIFOLD	1					
14	62T–13624–00	.PLATE,REED VALVE	1					
15	62T–13566–00	.GASKET	2					
16	62T–13674–00	.GASKET, AIR COOLER COVER 1	2					
17	6R8–13116–A0	.GASKET, PUMP CASE	1					
18	6M6–81365–A0	.GASKET, HOLE COVER	1					
19	62T–45127–00	.SEAL	1					
20	6D3–W0001–20	GASKET KIT FOR JET UNIT	1					
21	93101–25M55	.OIL SEAL	2					
22	93101–25M56	.OIL SEAL	1					
23	93210–464A3	.O-RING	1					
24	93101–21002	.OIL SEAL	1					
25	93101–21001	.OIL SEAL	1					
26	66V–42414–00	.O-RING	2					



GM6D100-9250

FIG. 29 REPAIR KIT 2

REF. NO.	PART NO.	DESCRIPTION	OTH					REMARKS
1	67E–W0093–00	CARBURETOR REPAIR KIT	1					
2	812–14235–00	.WASHER, NEEDLE	4					
3	812–14147–00	.O-RING	2					
4	6K8–14946–10	.METERING NEEDLE	2					
5	6K8–14564–00	.O-RING	2					
6	6K8–24411–20	.DIAPHRAGM	1					
7	6K8–24421–10	.VALVE, CHECK	1					
8	6K8–24431–20	.GASKET, FUEL PUMP 1	1					
9	6K8–14563–00	.O-RING	1					
10	61X–14916–16	.NEEDLE	2					
11	6R7–14541–00	.DIAPHRAGM, PUMP	2					
12	6K8–14536–11	.GASKET	2					
13	65U–14923–10	.SCREW, PILOT	2					
14	822–14235–00	.WASHER, NEEDLE	4					
15	583–14561–00	.O-RING	2					

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
F1K–U135C–00	15 – 11	F0V–U411C–10	26 – 7	F1V–U7555–00	22 – 8	F1W–U828M–00	13 – 1	90119–06897	8 – 12	90267–329UR	21 – 25
F1K–U142D–00	25 – 4	F1K–U411H–00	27 – 2	F1K–U7557–01	8 – 45		13 – 23	90119–069UB	8 – 22	90267–40935	20 – 10
F1K–U143D–01	25 – 2	F1B–U415B–11	27 – 7	GJ3–U7560–01	22 – 23		13 – 27	90119–069UH	15 – 18	90267–47801	17 – 12
F1K–U143E–01	25 – 3	GJ3–U416H–01	27 – 10	F1K–U757E–01	8 – 49		16 – 8		15 – 20	90267–48802	13 – 24
F1K–U1467–01	24 – 38	F1V–U417F–20	26 – 1	F1K–U757F–01	8 – 50		18 – 3		24 – 42		18 – 4
F1K–U1468–03	24 – 41	F1V–U417G–20	26 – 2	F1K–U759B–00	21 – 38		18 – 9	90119–069UP	19 – 5		21 – 12
GK5–U146F–00	23 – 5	F1V–U417H–20	26 – 3	GJ1–U759B–00	21 – 16		20 – 17	90119–08823	1 – 31		22 – 15
F1V–U146H–01	1 – 30	F1V–U417J–20	26 – 4	F1K–U759C–00	15 – 23		21 – 11		8 – 40		22 – 21
F1K–U1552–00	24 – 1	F1V–U417K–20	26 – 5		16 – 36		22 – 14	90119–08836	24 – 40	90267–48806	18 – 14
GP7–U155D–01	24 – 2	F1V–U417L–20	26 – 6		21 – 41		22 – 20	90119–08840	8 – 34		24 – 39
GP7–U155F–00	24 – 3	GA9–U418F–00	27 – 11	GJ1–U759C–00	21 – 17	F1G–U8572–02	8 – 41	90119–08856	1 – 28	90267–48809	15 – 3
F1K–U156E–01	25 – 1	F1K–U41B1–11	27 – 3	F1W–U759C–01	21 – 39	F1K–U8577–01	8 – 42	90119–089U7	8 – 55	90267–48824	14 – 15
F1B–U1653–01	16 – 18	F1B–U41B1–21	27 – 4	GH1–U759D–00	21 – 18	F1K–U883B–00	9 – 20	90119–089UU	9 – 18		14 – 17
F1K–U1949–00	24 – 45	F0V–U41B1–31	27 – 5	F1B–U761D–02	16 – 7	F1K–U883E–01	9 – 15		24 – 44	90267–489U1	13 – 8
F1K–U2103–00	15 – 2	F1B–U41B2–01	27 – 6	GU2–U7711–01	21 – 14	F1S–U883N–01	16 – 25	90119–08M11	6 – 11		20 – 15
F1K–U2127–00	18 – 1	F0V–U41DB–12	27 – 8	F1V–U775B–00	20 – 1	F1S–U883P–01	16 – 26	90119–08M55	1 – 18		21 – 35
F1K–U213G–00	18 – 2	F0V–U41E1–41	27 – 12	F1V–U776C–00	20 – 12	F1X–U883T–01	16 – 27	90119–08M96	1 – 13		22 – 5
F1V–U2155–01	9 – 17	F1B–U41F5–21	27 – 9	F0X–U778B–00	20 – 6	F1V–U892F–00	22 – 2	90119–10804	19 – 18		22 – 7
F1K–U2187–00	18 – 12	F1K–U471E–03	15 – 13	GJ3–U778C–00	20 – 4	62T–W0001–02	28 – 1	90119–10806	8 – 31	90267–489U2	21 – 5
F1K–U2188–00	18 – 13	F1K–U475F–01	15 – 21	F0X–U778D–00	20 – 7	6D3–W0001–20	28 – 20	90119–10809	8 – 44	90267–489U6	13 – 3
F1S–U2280–00	16 – 30	F1W–U491K–00	17 – 3	F0X–U778E–01	20 – 5	62T–W0004–00	3 – 14	90119–10810	8 – 4		13 – 30
F1S–U2285–00	16 – 31	GP7–U4953–10	16 – 17	F0X–U778H–01	20 – 11	62T–W0090–03–8S	1 – 14	90119–10M00	1 – 24		18 – 11
F1K–U2501–02	17 – 1		19 – 14	EU0–U7817–00	7 – 22	67E–W0093–00	29 – 1	90119–10M01	1 – 26		20 – 19
F1K–U2512–03	17 – 7	F1K–U515A–00	15 – 8	F1V–U781E–01	20 – 14	90101–069U0	8 – 53	90119–10M02	1 – 23		21 – 9
F1K–U2519–20	17 – 8	F1K–U516N–60–P0	14 – 1	GP7–U7831–11	21 – 19	90105–06826	15 – 15	90119–10M03	1 – 25	90267–489U8	16 – 10
F1K–U251D–01	17 – 10	F1K–U517B–60–P0	15 – 1	GP7–U7832–01	21 – 20	90105–08860	16 – 28	90119–10M07	1 – 7	90269–08801	15 – 22
F1K–U251E–01	17 – 11	F1K–U517D–05	15 – 10	GP7–U7833–11	21 – 21	90105–10M60	6 – 4	90119–10M17	6 – 45	90269–09805	14 – 3
F1K–U2521–02	17 – 2	F1K–U517F–01	15 – 19	GP7–U7834–00	21 – 24		6 – 25	90119–10M56	1 – 6	90280–05013	10 – 12
F1K–U2663–00	15 – 4	F1K–U517H–01	14 – 9	EU0–U7835–00	20 – 8	90105–10M88	6 – 46	90149–03930	23 – 13	90340–08M04	1 – 10
F1K–U2664–01	19 – 3	F1K–U517R–00	15 – 12	GP7–U7835–00	21 – 22	90109–06832	9 – 16	90149–05903	25 – 6	90380–12M29	1 – 17
F1K–U266B–00	15 – 5	F1K–U518E–04	15 – 9	GP7–U783F–00	21 – 26	90109–06M66	3 – 31	90150–05807	13 – 22		10 – 15
F1K–U266C–00	14 – 4	F1K–U519D–00	14 – 13	F1V–U7844–00	21 – 27	90109–08041	8 – 46	90154–06017	25 – 5	90387–06080	8 – 51
F1K–U271B–04	19 – 9	F1K–U5772–03	13 – 7	F0D–U7856–10	21 – 33	90109–08M56	1 – 20	90159–04800	7 – 21	90387–06M60	9 – 13
F1K–U2723–00	14 – 2		21 – 34	GJ3–U7856–10	21 – 32	90109–10M47	10 – 13	90159–059U2	15 – 7	90387–08M06	8 – 35
F1K–U273B–05	8 – 39		22 – 6	F0D–U785G–10	13 – 10	90110–05908	24 – 4	90167–04003	25 – 7	90430–08020	1 – 11
F1V–U273C–01	13 – 21	F1K–U5983–01	15 – 24	GP7–U785H–00	21 – 30	90110–06040	16 – 24	90169–049U1	21 – 23		28 – 3
F1K–U283B–02	15 – 14	F1V–U721B–03	1 – 29	GU2–U785H–00	20 – 20	90111–05008	13 – 15	90169–059U1	17 – 9	90430–12002	8 – 48
F1K–U351H–10	17 – 14	F0M–U7252–00	23 – 9	F1V–U815D–00	12 – 1	90111–05028	24 – 35	90170–22187	7 – 19	90445–07008	5 – 13
F1K–U351J–10	17 – 15	F1S–U725E–01	8 – 36	F2N–U8169–00	16 – 29	90111–06803	17 – 4	90179–08M15	3 – 4	90445–07009	5 – 8
F1K–U351K–10	17 – 16	EU0–U7354–00–01	1 – 33	F1K–U8211–01	13 – 6	90116–08M60	3 – 3	90183–06902	14 – 7	90445–10036	7 – 4
F1K–U351M–10	17 – 17	EU0–U7354–00–03	1 – 33	EU0–U821D–00	22 – 3	90119–059U4	22 – 25	90201–06906	23 – 6	90445–10037	7 – 1
F1K–U3581–10	17 – 13	EU0–U7354–00–05	1 – 33	F1K–U821D–01	13 – 9	90119–05M02	3 – 36	90201–06M31	3 – 32	90445–11006	7 – 12
F1K–U371A–12	19 – 1	EU0–U7354–00–10	1 – 33	F1K–U8221–00	13 – 5	90119–06820	19 – 10	90201–099U3	1 – 32	90445–11008	7 – 14
F1K–U371B–10	19 – 2	EU0–U7354–00–20	1 – 33	F1S–U8221–00	21 – 40	90119–06827	8 – 52		19 – 7	90445–11037	5 – 2
F1K–U3774–00	19 – 17	F1V–U7437–01	14 – 14	F0V–U824B–04	13 – 18	90119–06882	14 – 8	90201–10801	8 – 37	90445–11040	7 – 10
F1K–U378C–00	19 – 6	F1V–U7437–10	14 – 16	GJ8–U824C–02	13 – 20	90119–06891	9 – 12	90201–20M04	2 – 22	90445–14008	8 – 28
F1B–U3850–02	19 – 4	GA9–U7525–00	22 – 24	F1V–U826C–01	19 – 15	90119–06893	8 – 6	90201–24800	9 – 11	90445–14M14	6 – 50
F1B–U411C–02	27 – 1	GJ3–U7550–00	22 – 1	F1K–U828K–00	15 – 25	90119–06896	8 – 43	90202–229U1	7 – 20	90445–14M24	6 – 12

NUMERICAL INDEX